DICKSON Touchscreen Logger User Manual - FT500/FT520/FT525/FT535/FH520/FH525/FH535

Getting Started

Your Color Touch Screen Logger includes the following

- AC Adapter, Manual, Standard Dickson Certificate of Calibration
  (Flash Memory Card, USB Download Cable and DicksonWare Software are sold separately)

Presets

Model: FT500 /FT520/FT525/FT530	Model: FH520/525/535
Time Scale:	Time Scale:
1 Hour / Sample every 6 sec.	1 Hour / Sample every 6 sec.
Temperature Range: 0 to 100	Temperature Range: 0 to 100
	Humidity Range: 0 to 100
Unit of Measure: Deg. F	Unit of Measure: Deg. F; %RH
Alarm: OFF	Alarm: OFF

How the Touchscreen Works

- The Touchscreen is a data logger with a large real time graphing display.

- Logging
  Up to 32,000 data points can be stored at any time. The default logger setting is Wrap When Full. This means that once all 32,000 data points are used, the next data point will write over the oldest data point. If using a two channel model, up to 16,000 data points are stored per channel.

- Time Scale (X Axis)
  - The graph X axis represents time. Up to 600 sample points are displayed on the graph at any time. When setting the time scale for the X axis, you are telling the logger to collect 600 data points within a set period of time. For example when selecting a Time Scale of 1 hour, you will see 1 hours worth of data on the graph at any time. The logger calculates that a 6 second sample rate is required to fill the graph in an hour. The Scroll feature will allow you to view data older than 1 hour that has shifted off the graph.
  - The Preset Time Scales and correlating Sample Rates are:
    - 1 Hour = 6 Second Sample Rate
    - 8 Hour = 48 Second Sample Rate
    - 1 Day = 2 minute 24 second Sample Rate
    - 3 Day = 7 minute 12 second Sample Rate
    - 7 Day = 16 minute 48 second Sample Rate
    - Custom = Any Time Scale from a minimum of 10 Minutes (1 second Sample Rate) up to 31 days (1 hour, 14 minute and 25 second Sample Rate)
  - Changing the Time Scale will clear the logger of all saved data.

- Ranges (Y Axis)
  - The graph Y axis represents the set ranges for each channel. The ranges selected can not exceed the full range specified for the model in use.
  - Changing the Ranges will not clear the logger.

- Downloading Data
  - In order to download data to a PC, DicksonWare v17.1 or better is required.
  - The logger must be cleared via DicksonWare by USB connection to the PC before any data can be logged and downloaded.
  - Logged data can be downloaded via a USB connection or to a Flash Memory Card.

- Viewing Data
  - VIEW There are 3 user selectable views, press the "View" button to scroll through each. NOTE: Current Reading box will update with current readings every 10 seconds regardless of sample rate. If the sample rate is less than 10 seconds, the graph will update with all new readings every 10 seconds when the Current Readings window is refreshed.
  - Scroll Bar
    - Once the graph is full the "Scroll" bar will appear.
    - Press and drag the bar to the right and left to view all saved data.

- When the scroll bar is in the left most position, the most recently saved data is displayed on the graph. When in the right most position, the oldest saved data is displayed on the graph.

- Zoom
  - Press the ZOOM button to activate Zoom
  - Place your finger on the graph and drag along the graph to draw a box over the desired data.
  - To exit Zoom, press UNZOOM. The graph will default to the standard Time Scale with the most recent data displayed.

Unit Operation

Quick Start

The Touchscreen Logger is a PC device and must be set and restarted before using.

1) Connect the AC adapter to the Logger then plug into a standard electrical outlet. Slide the power switch up to the "On" position.
2) Set Time: Press "Menu", "Setup", "Set Time" set then "Save", "OK"
3) Set Date: Press "Menu", "Setup", "Set Date" set then "Save", "OK"
4) Set Time Scale: Press "Menu", "Set Scales", "Set Time Scales", set then "Save", "OK"
5) Turn Logger Off wait 10 seconds then turn the unit On.
6) Press "Current" to see current readings. If no readings are displayed, repeat steps above. If readings are displayed the logger is ready.
7) **If using DicksonWare to view saved data, the Touchscreen must be cleared with DicksonWare via USB connection before logging begins or data will be invalid.**

Configuring the Touchscreen Logger

- Set Time Scale: This is the amount of saved logged data that will display on the graph
- Set Channel 1 and 2 Unit of Measure and Range(s): "Menu", "Setup", "Set Scales", "Set Ranges"
- Set High and Low Alarms: "Menu", "Setup", "Set Alarms"

Data Export

Logged data can be exported using a USB cable or Flash Memory Card. (To view exported data, DicksonWare software is required.) **NOTE: Unit must be cleared via DicksonWare v17.1 or greater before logging and downloading data.**

- **Exporting via USB:**
  - Bring the Touchscreen along with the AC adapter to a PC running DicksonWare.
  - Power on the Touchscreen via AC power and connect the Touchscreen to the PC via USB.
  - DicksonWare will recognize the Touchscreen.
  - Download saved data and clear.
- **Exporting via Flash Card:**
  - Insert Flash card into slot on the left side of the Touchscreen case.
  - Go to Menu then Download and press Start.
  - All saved data will be exported to the flash card.
  - Bring the Flash card to a PC running DicksonWare.
  - Insert Card into PC SD card slot and from the DicksonWare main screen select Flash Card - locate removable disk drive.
  - Download saved data and clear.
- **DicksonWare Features:**
  - All Touchscreen settings are to be made via the Touchscreen and are grayed out in Dicksonware with the exception of the following:
    - In "Setup" under "Samples" tab, Wrap When Full can be change to Stop When Full
    - In "Setup", "Identification", User ID, Calibration Date and Calibration Interval can be set
  - The Touchscreen can be downloaded and cleared via DicksonWare.
  - All downloaded data can be viewed in a graph or table and saved and exported.
  - The Touchscreen must be cleared in DicksonWare via USB connection before data can be logged and downloaded. If the unit is not cleared first, all date/time stamps will be incorrect.

Alarm Operation

- Alarm ON: Alarm setting arrows will appear on the graph to indicate min and max settings.
- Alarm Triggered: Out of range alarm setting arrow will blink, the alarm symbol will display and an audible alarm will sound.
  - To clear alarm press the display.
  - If the alarm condition still exists after two minutes or by the next sample (whichever is longer), the alarm will sound and display again.

- If the display is not pressed after 30 seconds, the alarm will stop sounding but will beep 2x every 5 minutes until the display is pressed

Note: Alarms will not sound when operating under battery power.

Relays

- FH535 features 2 (1 per channel) SPST 24VDC. 0.5A, NO/NC Relays. Relays do not operate under battery power. **Relay wiring diagram available at dicksondata.com.** Pin no. 1 is the lowest pin position. Pin no. 6 is the top pin position.
- Relay Operation:
  - When the unit enters an alarm condition the relays will activate.
  - If the user presses the display to clear the alarm, the relays will deactivate. If the alarm condition still exists after two minutes or by the next sample (whichever is longer), the relays will activate.
  - If the display is not pressed the relays will remain active until the readings fall back within the set range. If the readings move outside the min/max range again, the relays will reactivate regardless of whether the initial alarm condition has been cleared or not.

Minimum and Maximum Readings

- Min/Max readings displayed reflects the Min and Max for all samples currently **displayed** on the graph.
- When scrolling through logged data or zooming, the Min/Max readings will change to reflect the data being displayed.

Stop or Wrap When Full

Your Touch Screen logger is set to log continuously (wrap when full). In DicksonWare, under set-up/samples stop when full can be selected.

Power

The Touch Screen logger operates on a 120V AC adapter. Turning off the power switch also turns off backup battery power and will cause up to the last 30 minutes of data to be lost. A rechargeable battery provides backup for up to 12 hours. A UPS is recommended for longer backup life. When operating under backup power, the unit will continue to log but the display will automatically turn off to conserve power. The Touch Screen must run for 24 hours before the backup battery is fully charged.

If the backup battery is not charged and the logger looses power, the last 30 minutes of data will be lost. Turning off the logger while logging will result in non valid data points for the period of time where the logger was turned off.

Clear Logger

The Touchscreen Logger can be cleared via DicksonWare or by saving a current or new Time Scale or changing the Date or Time via the Touchscreen Menu.

Probes

- FT525
  - Features a hardwired Thermistor probe.
  - This probe can not be removed from the logger.
- FT520 & FT530
  - Features K-Thermocouple bead wire probes with mini connectors.
  - Bead wire probes can operate in conditions from -300 to 500F.
  - Probes can be removed and replaced with any K-TC probe with mini connector.
  - Dickson sells K-TC probes with stainless steel tips, piercing tips and ones that can operate in conditions up to 2000F.

  Note: Double check the K-TC probe range to ensure it covers the range being recorded.
- FH525 & FH535
  - Features temperature and humidity probes.
  - These probes can be removed from the unit for placement**, but they must not be swapped** with another probe.
  - The unit and probe are calibrated together and switching probes will invalidate calibration and throw off readings.
  - The probe **must be returned with the unit** when returned for calibration and repair.

Warranty: Dickson warrants this line of instruments will be free from defects in material and workmanship under normal use and service for a period of twelve months after delivery. This warranty does not cover routine calibration and battery replacement. For Specifications and Technical Support go to www.DicksonData.com or call 800.323.2448.